

Preparing For Your New Cabinets & Countertops

- The area where cabinets are going should be free of existing cabinetry. Appliances should be out of the kitchen area.
- All plumbing should be disconnected. If existing waterlines come up through the floor they should be capped at 6-8" above floor level.
- Walls should have final coat of paint, however, there may be some touchup required after cabinets & countertops are installed.
- Floors should be at the sub-floor stage. It is good for finish floor to go in after cabinets, which usually entails that our installer comes back to put on finish toekick.
- Electrical changes/additions should be discussed with an electrician & the designer.
- Discuss with the designer access to your home for delivery & installation personnel.
- Upon delivery the cabinets should be placed near the installation area.
- The installer prefers to work without interruption & should be able to set up tools nearby.
- The installer should be able to reach you to discuss placement of handles/knobs & other issues that may arise.
- Countertop installation depends on the type purchased. There will be a time lapse for scheduling final measure, manufacture & installation thereof. Discuss timelines with the designer & countertop personnel.